

# CB and GPS Car Antennas Quick Start Guide

## 1. Introduction

Dear Customer! Thank you for your purchase in TME! To protect the environment we have prepared for you this quick start guide. Before operating the unit, please read it carefully. Please visit [www.tme.eu](http://www.tme.eu) Illustrations in this manual are only example images and may differ from the actual item. It does not change their main characteristics.

## 2. Application

Devices designed to work with radio/CB radios.

## 3. Unit setup and operation

- Mount the antenna in the designated hole in the car body using mounting head or in case of internal antennas stick firmly to the windscreen or dashboard.
- Connect the antenna plugs into the appropriate jacks.
- In case of antennas with an amplifier, connect the power cord with the inducting cable in the radio set (usually blue one) marked as "remote".
- In case of CB antennas after installation antenna should be tuned using a reflectometer or antenna analyser.

## 4. Precautions

- Connect only to the 12V car installation.
- Do not disassemble the housing.
- Please observe the correct polarization.
- Use only as intended.
- The antenna must be mounted securely to prevent falling off while driving.
- The antenna may not protrude outside the contour of the vehicle otherwise than vertically.
- Not performing the antenna tuning can result in damage to the CB radio.



**Transfer Multisort Elektronik Sp. z o.o.**

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071  
tel. +48 42 645 54 44, fax +48 42 645 54 70, [export@tme.eu](mailto:export@tme.eu), [www.tme.eu](http://www.tme.eu)

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN