



MICROCHIP

HV582
96-Channel High-Voltage Driver IC
Evaluation Board
User's Guide

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, flexPWR, JukeBlox, KEELOQ, KEELOQ logo, Kleer, LANCheck, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC³² logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

The Embedded Control Solutions Company and mTouch are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, ECAN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, KleerNet, KleerNet logo, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, RightTouch logo, REAL ICE, SQI, Serial Quad I/O, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2015, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-0114-8

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =**

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC[®] MCUs and dsPIC[®] DSCs, KEELOQ[®] code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

HV582 96-Channel High Voltage Driver IC Evaluation Board User's Guide

Object of Declaration: HV582 96-Channel High-Voltage Driver IC Evaluation Board

EU Declaration of Conformity

Manufacturer: Microchip Technology Inc.
2355 W. Chandler Blvd.
Chandler, Arizona, 85224-6199
USA

This declaration of conformity is issued by the manufacturer.

The development/evaluation tool is designed to be used for research and development in a laboratory environment. This development/evaluation tool is not a Finished Appliance, nor is it intended for incorporation into Finished Appliances that are made commercially available as single functional units to end users under EU EMC Directive 2004/108/EC and as supported by the European Commission's Guide for the EMC Directive 2004/108/EC (8th February 2010).

This development/evaluation tool complies with EU RoHS2 Directive 2011/65/EU.

This development/evaluation tool, when incorporating wireless and radio-telecom functionality, is in compliance with the essential requirement and other relevant provisions of the R&TTE Directive 1999/5/EC and the FCC rules as stated in the declaration of conformity provided in the module datasheet and the module product page available at www.microchip.com.

For information regarding the exclusive, limited warranties applicable to Microchip products, please see Microchip's standard terms and conditions of sale, which are printed on our sales documentation and available at www.microchip.com.

Signed for and on behalf of Microchip Technology Inc. at Chandler, Arizona, USA


Derek Carlson
VP Development Tools

12-Sep-14
Date

NOTES:

Table of Contents

Preface	7
Introduction.....	7
Document Layout	7
Conventions Used in this Guide	8
Warranty Registration.....	8
Recommended Reading.....	9
The Microchip Web Site	9
Development Systems Customer Change Notification Service	9
Customer Support	10
Document Revision History	10
 Chapter 1. Product Overview	
1.1 Introduction	11
1.2 HV582 Device Overview	11
1.3 HV582 Evaluation Board Overview	11
1.4 HV582 Evaluation Board Kit Contents	13
 Chapter 2. Installation and Operation	
2.1 Getting Started	15
2.2 Setup Procedure	15
2.3 Using The Evaluation Board with a Generic Signal Pattern Generator	17
2.4 Using The Evaluation Board with the PIC32 Starter Kit	19
 Appendix A. Schematic and Layouts	
A.1 Introduction	25
A.2 Evaluation Board – Schematic	26
A.3 Evaluation Board – Top Silk	27
A.4 Evaluation Board – Top Copper and Silk	27
A.5 Evaluation Board – Top Copper	28
A.6 Evaluation Board – Ground Plane	28
A.7 Evaluation Board – Mid Layer 1	29
A.8 Evaluation Board – Mid Layer 2	29
A.9 Evaluation Board – Power Plane	30
A.10 Evaluation Board – Bottom Copper	30
A.11 Evaluation Board – Bottom Copper and Silk	31
A.12 Evaluation Board – Bottom Silk	31
 Appendix B. Bill of Materials (BOM)	
B.1 Bill Of Materials (BOM)	33
 Appendix C. HV582 Typical Waveforms	
C.1 Introduction	35
 Worldwide Sales and Service	40

NOTES:

Preface

NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a “DS” number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is “DSXXXXXXXXA”, where “XXXXXXXX” is the document number and “A” is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB® IDE online help. Select the Help menu, and then Topics to open a list of available online help files.

INTRODUCTION

This chapter contains general information that will be useful to know before using the HV582 96-Channel High-Voltage Driver IC Evaluation Board. Items discussed in this chapter include:

- [Document Layout](#)
- [Conventions Used in this Guide](#)
- [Warranty Registration](#)
- [Recommended Reading](#)
- [The Microchip Web Site](#)
- [Development Systems Customer Change Notification Service](#)
- [Customer Support](#)
- [Document Revision History](#)

DOCUMENT LAYOUT

This document describes how to use the HV582 96-Channel High-Voltage Driver IC Evaluation Board as a development tool. The manual layout is as follows:

- **Chapter 1. “Product Overview”** – Important information about the HV582 96-Channel High-Voltage Driver IC Evaluation Board.
- **Chapter 2. “Installation and Operation”** – This chapter includes a detailed description of each function of the HV582 96-Channel High-Voltage Driver IC Evaluation Board and instructions on how to use it.
- **Appendix A. “Schematic and Layouts”** – Shows the schematic and layout diagrams for the HV582 96-Channel High-Voltage Driver IC Evaluation Board.
- **Appendix B. “Bill of Materials (BOM)”** – Lists the parts used to build the HV582 96-Channel High-Voltage Driver IC Evaluation Board.
- **Appendix C. “HV582 Typical Waveforms”** – Describes the various plots and waveforms for the HV582 96-Channel High-Voltage Driver IC Evaluation Board.

CONVENTIONS USED IN THIS GUIDE

This manual uses the following documentation conventions:

DOCUMENTATION CONVENTIONS

Description	Represents	Examples
Arial font:		
Italic characters	Referenced books	<i>MPLAB[®] IDE User's Guide</i>
	Emphasized text	...is the <i>only</i> compiler...
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, italic text with right angle bracket	A menu path	<u><i>File>Save</i></u>
Bold characters	A dialog button	Click OK
	A tab	Click the Power tab
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1
Text in angle brackets < >	A key on the keyboard	Press <Enter>, <F1>
Courier New font:		
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	0xFF, 'A'
Italic Courier New	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets []	Optional arguments	mcc18 [options] <i>file</i> [options]
Curly brackets and pipe character: { }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses...	Replaces repeated text	var_name [, var_name...]
	Represents code supplied by user	void main (void) { ... }

WARRANTY REGISTRATION

Please complete the enclosed Warranty Registration Card and mail it promptly. Sending in the Warranty Registration Card entitles users to receive new product updates. Interim software releases are available at the Microchip web site.

RECOMMENDED READING

This user's guide describes how to use the HV582 96-Channel High-Voltage Driver IC Evaluation Board. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

- **HV582 Data Sheet – “96-Channel Serial to Parallel Converter with Push-Pull Outputs” (DS20005455).**

Additional documentation (including schematic and code samples) is available under the PIC32 Starter Kit (DM320001) section on the website.

THE MICROCHIP WEB SITE

Microchip provides online support via our web site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

DEVELOPMENT SYSTEMS CUSTOMER CHANGE NOTIFICATION SERVICE

Microchip's customer notification service helps customers stay up-to-date on Microchip products. Subscribers receive e-mail notification when there are changes, updates, revisions, or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at www.microchip.com, click on Customer Change Notification and follow the registration instructions.

The Development Systems product group categories are:

- **Compilers** – The latest information on Microchip C compilers, assemblers, linkers and other language tools. These include all MPLAB® C compilers, all MPLAB assemblers (including MPASM™ assembler), all MPLAB linkers (including MPLINK™ object linker), and all MPLAB librarians (including MPLIB™ object librarian).
- **Emulators** – the latest information on Microchip in-circuit emulators. This includes the MPLAB REAL ICE™ and MPLAB ICE 2000 in-circuit emulators.
- **In-Circuit Debuggers** – the latest information on the Microchip in-circuit debuggers. This includes MPLAB ICD 3 in-circuit debuggers and PICKit™ 3 debug express.
- **MPLAB IDE** – the latest information on Microchip MPLAB IDE, the Windows Integrated Development Environment for development systems tools. This is focused on the MPLAB IDE, MPLAB IDE Project Manager, MPLAB Editor, and MPLAB SIM simulator, as well as general editing and debugging features.
- **Programmers** – the latest information on Microchip programmers. These include production programmers such as MPLAB REAL ICE in-circuit emulator, MPLAB ICD 3 in-circuit debugger, and MPLAB PM3 device programmers. Also included are nonproduction development programmers such as PICSTART Plus and PICKit 2 and 3.

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or FAE for support. Local sales offices are also available to help customers. A list of sales offices and locations is included in the back of this document.

Technical support is available through the web site at:

<http://www.microchip.com/support>

DOCUMENT REVISION HISTORY

Revision A (December 2015)

- Initial release of this document.

Chapter 1. Product Overview

1.1 INTRODUCTION

This chapter covers the following topics:

- [HV582 Device Overview](#)
- [HV582 Evaluation Board Overview](#)
- [HV582 Evaluation Board Kit Contents](#)

1.2 HV582 DEVICE OVERVIEW

The HV582 is a unipolar 96-channel, low-voltage serial to high-voltage parallel converter with push-pull outputs, dedicated to printer driver and plasma display applications. The device has been designed for applications requiring high channel count and high output voltage swing (0-80V) with current sinking and sourcing capabilities of ± 75 mA.

The device consists of six parallel 16-bit shift registers, a 96-bit latch, and 96 high-voltage outputs. The 16-bit shift registers can operate up to a 30 MHz speed rate, allowing 180 MHz data rates due to the parallel arrangement. The parallel arrangement of the registers permits six times the speed of a single register (30 MHz x 6 16-bit shift registers), providing a fast update rate for the 96 output channels. Data flow can be shifted from a clockwise to a counterclockwise direction via the DIR pin. All high-voltage outputs can be forced to a low-level, high-level or high-impedance state (high Z) or to alter their polarity state through the \overline{OL} , OH, OE and POL pins, respectively.

1.3 HV582 EVALUATION BOARD OVERVIEW

The HV582 96-Channel High-Voltage Drive IC Evaluation Board facilitates quick implementation for display and printer driver applications due to its flexible input/output connection interface.

The evaluation board is designed to be operated with the Microchip PIC32 Starter Kit (DM320001), or with a generic signal pattern generator via the dedicated J5 pin header connector (see [Figure 1-1](#)).

There are 32 test-point pads corresponding to the first and the last 16-bit registers (D1A/D1B and D6A/D6B) that control the high-voltage outputs: HV_{OUT}1 to 16 and HV_{OUT}81 to 96. Ground pads are provided along with the test-point pads to facilitate the analysis of the high-voltage output channels. Refer to [Figure 1-1](#) and to the HV582 Data Sheet.

All output channels are available via a 160-position, high-density array, female connector, where only 96 positions are used (refer to [Evaluation Board – Schematic](#) in [Appendix A. “Schematic and Layouts”](#) for more details).

HV582 96-Channel High-Voltage Driver IC Evaluation Board User's Guide

The HV582 contains six parallel 16-bit shift registers. Each 16-bit shift register features two ports that can be set as either inputs or outputs by controlling the DIR pin, as shown in the following list:

- setting the DIR pin high configures DnB pins as inputs and DnA pins as outputs (counterclockwise input data)
- setting the DIR pin low enables DnA pins as inputs and DnB pins as outputs (clockwise input data)

Shunt (zero Ohm) resistors are placed right after the pin header connectors (D1A to D6A) to facilitate the adjustment of the input registers in any desired manner.

Note: The HV582 96-Channel High-Voltage Drive IC Evaluation Board comes equipped with shunt resistors only on the DnA pins. Shunt resistors are not installed on the DnB pins.

1.3.1 HV582 Evaluation Board Block Diagram

Figure 1-1 presents the HV582 96-Channel High-Voltage Drive IC Evaluation Board block diagram with the main sections labeled and explained.




FIGURE 1-1: HV582 96-Channel High-Voltage Drive IC Evaluation Board Block Diagram.

1.4 HV582 EVALUATION BOARD KIT CONTENTS

The HV582 96-Channel High-Voltage Drive IC Evaluation Board Kit includes:

- HV582 96-Channel High-Voltage Drive IC Evaluation Board (ADM00697)
- Important Information Sheet




FIGURE 1-2: HV582 96-Channel High-Voltage Drive IC Evaluation Board – Top View.

NOTES:

Chapter 2. Installation and Operation

2.1 GETTING STARTED

The HV582 96-Channel High-Voltage Driver IC Evaluation Board is fully assembled and tested.

2.1.1 Tools Required for Operation

- A low DC power supply for V_{DD} (and V_{DD_PIC}) that can produce 5V
- A high DC power supply for V_{PP} with a voltage range up to +80V
- A logic signal driver: PIC32 Starter Kit (DM320001) or a generic signal pattern generator
- An oscilloscope and/or a multimeter to observe waveforms and measure electrical parameters

2.2 SETUP PROCEDURE

To prepare the HV582 96-Channel High-Voltage Driver IC Evaluation Board for operation, the following steps must be followed:

WARNING

Read the *HV582 96-Channel High-Voltage Driver IC Evaluation Board User's Guide* (this document) fully before proceeding to board setup.

1. Connect the power supplies by following the steps indicated by this power-up sequence:
 - a) Connect GND
 - b) Apply V_{DD}
 - c) Connect V_{DD_PIC} (if PIC32 Starter Kit is mounted and used) ⁽¹⁾
 - d) Set logic input signals to a known state
 - e) Apply V_{PP}

Note 1: If the PIC32 Starter Kit is used and connected to the USB debug cable there is no need to power the V_{DD_PIC} pin.

Note: To power down the board, follow the reverse order of the power-up sequence.




FIGURE 2-1: Board Power-Up Sequence.

Step 2. Apply the voltage settings by following the sequence shown in [Table 2-1](#).

TABLE 2-1: VOLTAGE SETTINGS

Sequence Number	Terminal Name	Description
1	GND	Ground
2	V _{DD}	5.0V, logic power supply for HV582
3	VDD_PIC	5.0V, power supply for PIC32 Starter Kit ⁽¹⁾
4	V _{PP}	+10V to +80V, high-voltage power supply for all HV _{OUT} n

Note 1: If the PIC32 Starter Kit is used and not connected to the USB debug cable.

After following the power-up sequence and applying the voltage settings correctly, the evaluation board is ready to operate.

The HV582 96-Channel High-Voltage Driver IC Evaluation Board can be driven by a generic signal pattern generator or by the suggested PIC32 Starter Kit (DM320001). [Section 2.3 “Using The Evaluation Board with a Generic Signal Pattern Generator”](#) and [Section 2.4 “Using The Evaluation Board with the PIC32 Starter Kit”](#) elaborate on the operation and evaluation process in detail.

2.3 USING THE EVALUATION BOARD WITH A GENERIC SIGNAL PATTERN GENERATOR

2.3.1 Introduction

The HV582 96-Channel High-Voltage Driver IC Evaluation Board can be operated by a generic logic signal pattern generator, or by any signal driver, via the J5 pin header connector (pin header not installed).




FIGURE 2-2: J5 Pin Header Connector.

The user must ensure the minimum DC and AC electrical parameters are achieved by the signal pattern generator. For more information, refer to the HV582 data sheet (DS20005455).

2.3.2 Operating the Evaluation Board

When operating the evaluation board with a generic logic signal pattern generator, the VDD_PIC pin should not be powered on. The VDD_PIC pin is an optional power pin used only for the PIC32 Starter Kit (DM320001).

In case a read operation is required for the signal driver, it is recommended to operate the pattern generator at the same voltage potential as the evaluation board (V_{DD}). If, for instance, the signal pattern generator is operating at a lower voltage (e.g. 3.3V) than that of the evaluation board (5.0V), this will cause the ESD protection diodes of the signal generator to forward bias and possibly damage the board.

WARNING

If a read-back operation is required by the generic signal pattern generator (or by any signal driver), the operational voltage level of the logic signals must be equal to the voltage potential of the evaluation board (V_{DD}).

Figure 2-3 presents the logic diagram of a sample data transmission for testing and understanding the functionality of the HV582.




FIGURE 2-3: Sample Data Transmission Timing Diagram.

2.4 USING THE EVALUATION BOARD WITH THE PIC32 STARTER KIT

2.4.1 Introduction

The HV582 96-Channel High-Voltage Driver IC Evaluation Board can be operated by the Microchip PIC32 Starter Kit (DM320001) via the FX10A-120S/12-SV(71) connector, J2 (see [Figure 2-4](#)).

Note: Several PIC32 Starter kits might be compatible with the HV582 Evaluation Board, but only the DM320001 is supported with code.

2.4.2 Software Requirements

In order to operate the PIC32 Starter Kit, the MPLAB X IDE software and the MPLAB XC32 Compiler must be installed in the user's system. Software and compilers are available for download on the Microchip website at www.microchip.com.

For detailed information regarding the installation and usage of MPLAB X IDE software, refer to *MPLAB X IDE User's Guide* (DS50002027).

2.4.3 Connecting the PIC32 Starter Kit to the HV582 Evaluation Board

Mount the PIC32 Starter Kit (DM320001) onto the J2 connector before powering up the board. Follow the power-up sequence and apply the voltage settings indicated in [Section 2.2 "Setup Procedure"](#).




FIGURE 2-4: FX10A-120S/12-SV(71) connector, J2.

2.4.4 PIC32 Starter Kit Software Code

The source code for driving the HV582 96-Channel High-Voltage Driver IC Evaluation Board, `PIC32_HV582.X`, is available for download on the Microchip web site. The objective of the code is to provide a starting platform for using the HV582 evaluation board.

The code flowchart is presented in [Figure 2-5](#).




FIGURE 2-5: Program-Code Flowchart.

Table 2-2 provides a summary of the software code operation.

TABLE 2-2: SOFTWARE CODE OPERATION ⁽¹⁾

Switch	Description
SW1	LED 1 turns on, data is sent to input registers D1A, D2A, D3A, D4A, D5A and D6A
SW2	LED 2 turns on, makes all (HV _{OUTn}) High-Voltage channels low (GND)
SW3	LED 3 turns on, makes all (HV _{OUTn}) High-Voltage channels high (VPP)

Note 1: Push-button switches are located on the PIC32 Starter Kit, see Figure 2-6 and Section 2.4.6 “Modifying the Control Signals and Data in the Code”.






FIGURE 2-6: HV582 96-Channel High-Voltage Driver IC Evaluation Board with PIC32 Starter Kit (DM320001) connected on J2 – Top View.

2.4.5 Programming the PIC32 Starter Kit

This section assumes that MPLAB X IDE software and the MPLAB XC32 Compiler are installed on the user’s system and the PIC32 Starter Kit is connected to the PC via the USB debug cable.

To load the PIC32_HV582.X code, follow these steps:

1. Open MPLAB X IDE and then PIC32_HV582.X program code.
2. Select **Clean and Build Project** icon (). Ignore warning messages.
3. Select **Make and Program Device** icon ().




FIGURE 2-7: MPLAB X IDE Workspace.

2.4.6 Modifying the Control Signals and Data in the Code

To modify the control signals and the data to be sent to the HV582 evaluation board, open the HV582_defines.h file located under the Header Files folder.

To change the control signals, LE, OE, DIR, RST, \overline{OH} , \overline{OL} and POL, locate the section in the file labeled INPUT CONTROL SIGNALS (see Figure 2-8) and modify accordingly. Data transmission is controlled by pressing the push-button switches on the PIC32 Starter Kit (see Figure 2-6). The user can select one of three available cases:

- HV582_CASE_1_ENABLE and HV582_CASE_1_DISABLE control the data transmission; selectable by pressing SW1
- HV582_CASE_2_ENABLE makes all HV_{OUTn} channels low; selectable by pressing SW2
- HV582_CASE_3_ENABLE makes all HV_{OUTn} channels high; selectable by pressing SW3

```
//=====//  
//-----//  
//----- INPUT CONTROL SIGNALS -----//  
//-----//  
//=====//  
#define HV582_CASE_1_ENABLE 0b0000000110010 // (LSB)LE = LOW, OE = HIGH, DIR = LOW, RST = LOW, OH = HIGH, OL = HIGH, POL = LOW  
#define HV582_CASE_1_DISABLE 0b0000000110011 // (LSB)LE = HIGH, OE = HIGH, DIR = LOW, RST = LOW, OH = HIGH, OL = HIGH, POL = LOW  
#define HV582_CASE_2_ENABLE 0b0000000010010 // (LSB)LE = LOW, OE = HIGH, DIR = LOW, RST = LOW, OH = HIGH, OL = LOW, POL = LOW  
#define HV582_CASE_3_ENABLE 0b0000000100010 // (LSB)LE = LOW, OE = HIGH, DIR = LOW, RST = LOW, OH = LOW, OL = HIGH, POL = LOW
```

FIGURE 2-8: Input Control Signals: LE, OE, DIR, RST, \overline{OH} , \overline{OL} and POL.

To change the data to be sent to the input registers of the HV582, scroll at the bottom of the file and locate the section DATA TO SEND TO REGISTERS and change the values as desired. See Figure 2-9.

The HV582 consists of six 16-bit shift registers. The distribution of the input/output pins to registers is detailed in [Table 2-3](#).

TABLE 2-3: PIN-TO-REGISTER ASSIGNMENT

16-bit shift registers	Corresponding input/output pins
first register	D1A/D1B
second register	D2A/D2B
third register	D3A/D3B
fourth register	D4A/D4B
fifth register	D5A/D5B
sixth register	D6A/D6B

In the code, `DATA_1` corresponds to the first bit of data to be send to all of the six registers. The Least Significant Bit (LSB) corresponds first to D1A/D1B, second to D2A/D2B, third to D3A/D3B, fourth to D4A/D4B, fifth to D5A/D5B, and sixth to D6A/D6B.

```

//=====//
//-----//
//----- DATA TO SEND TO REGISTERS -----//
//-----//
//=====//

#define DATA_1 0b000001 //(LSB)D1A/B-> 1, D2A/B-> 0, D3A/B-> 0, D4A/B-> 0, D5A/B-> 0, D6A/B-> 0
#define DATA_2 0b100000
#define DATA_3 0b011111
#define DATA_4 0b111110
#define DATA_5 0b011110
#define DATA_6 0b111110
#define DATA_7 0b011110
#define DATA_8 0b111110
#define DATA_9 0b011110
#define DATA_10 0b111110
#define DATA_11 0b011110
#define DATA_12 0b101110
#define DATA_13 0b011110
#define DATA_14 0b111110
#define DATA_15 0b000000
#define DATA_16 0b101010
    
```

FIGURE 2-9: Data to Send to the HV582 Input Registers.

The code flow is specified in the `main.c` file (see [Figure 2-7](#)) located under the Source Files folder.

NOTICE

By default, the code provided sends data into the DnA input registers of the HV582.

WARNING

The PIC32 Starter Kit (DM320001) cannot be used to read data back from the HV582 Evaluation Board because of the difference in logic voltage level: 3.3V (PIC32) vs 5.0V (V_{DD}). If used, this will cause the ESD protection diodes in the PIC32 board to forward bias and possibly damage the board.

NOTES:


Appendix A. Schematic and Layouts

A.1 INTRODUCTION


This appendix contains the following schematics and layouts for the HV582 96-Channel High-Voltage Drive IC Evaluation Board.

- Evaluation Board – Schematic
- Evaluation Board – Top Silk
- Evaluation Board – Top Copper and Silk
- Evaluation Board – Top Copper
- Evaluation Board – Ground Plane
- Evaluation Board – Mid Layer 1
- Evaluation Board – Mid Layer 2
- Evaluation Board – Power Plane
- Evaluation Board – Bottom Copper
- Evaluation Board – Bottom Copper and Silk
- Evaluation Board – Bottom Silk


A.2 EVALUATION BOARD – SCHEMATIC




A.3 EVALUATION BOARD – TOP SILK




A.4 EVALUATION BOARD – TOP COPPER AND SILK




A.5 EVALUATION BOARD – TOP COPPER




A.6 EVALUATION BOARD – GROUND PLANE




A.7 EVALUATION BOARD – MID LAYER 1




A.8 EVALUATION BOARD – MID LAYER 2




A.9 EVALUATION BOARD – POWER PLANE




A.10 EVALUATION BOARD – BOTTOM COPPER



A.11 EVALUATION BOARD – BOTTOM COPPER AND SILK



A.12 EVALUATION BOARD – BOTTOM SILK



NOTES:

Appendix B. Bill of Materials (BOM)

B.1 BILL OF MATERIALS (BOM)

Qty.	Reference	Description	Manufacturer	Part Number
1	C1	Ceramic capacitor, 1 μ F 100V	AVX Corporation	12061C105KAT2A
1	C2	Ceramic capacitor, 0.1 μ F 25V	AVX Corporation	06033C104JAT2A
1	J1	160 position high-density array connector, female	Molex, LLC	0465574145
1	J2	Board-to-board high-speed connector, 120 positions, w/post, SMD	Hirose Electric Co. Ltd.	FX10A-120S/12-SV(71)
1	J3	Connector header, 4 positions, 100" SGL, gold	Samtec Inc.	TSW-104-07-G-S
4	GND	Connector PC pin, circular, 0.030 diameter, gold	Mill-Max Manufacturing Corp.	3132-0-00-15-00-00-08-0
6	N/A	Rubber bumper square, 0.5"L x 0.5"W, black	3M	SJ-5518 (BLACK)
1	PCB	HV582 96-Channel High Voltage Driver IC Evaluation Board – Printed Circuit Board	—	04-10466
6	R1, R3, R5, R7, R9, R11	Resistor SMD 0.0 Ohm jumper 1/10W	Stackpole Electronics Inc.	RMCF0603ZT0R00
6	R2, R4, R6, R8, R10, R12	DO NOT POPULATE	—	—
1	U1	HV582, unipolar 96-channel low-voltage serial to high-voltage parallel converter with push-pull outputs	Microchip Technology Inc.	HV582GA-G

Note: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

NOTES:

Appendix C. HV582 Typical Waveforms

C.1 INTRODUCTION

Waveforms presented in this section correspond to two consecutive data transmissions: Transmission 1 and Transmission 2. No load is connected to the output channels.

C.1.1 Transmission 1

Turns on **HV_{OUT16}**, **14**, and **1**. Turns off the rest of the other HV_{OUT} channels.

The control signals not shown in the waveforms have the states listed in [Table C-1](#):

TABLE C-1: TRANSMISSION 1: CONTROL SIGNAL STATES

Signal	State
DIR	Low
RST	Low
$\overline{\text{OH}}$	High
$\overline{\text{OL}}$	High
POL	Low
D2A	Low
D3A	Low
D4A	Low
D5A	Low
D6A	Low




FIGURE C-1: *Transmission 1.*




FIGURE C-2: Transmission 1: HV_{OUT1} displayed instead of OE.




FIGURE C-3: Transmission 1: Zoom version, LE and HV_{OUT1}.

C.1.2 Transmission 2

Turns on **HV_{OUT16}** and **HV_{OUT14}**. Turns off **HV_{OUT1}** and the rest of the HV_{OUT} channels. This transmission illustrates the turn-off transition for HV_{OUT1}, which is at high level (V_{PP}) due to Transmission 1.

The control signals not shown in the waveforms have the states listed in [Table C-2](#):

TABLE C-2: TRANSMISSION 2: CONTROL SIGNAL STATES

Signal	State
DIR	Low
RST	Low
$\overline{\text{OH}}$	High
$\overline{\text{OL}}$	High
POL	Low
D2A	Low
D3A	Low
D4A	Low
D5A	Low
D6A	Low




FIGURE C-4: Transmission 2.




FIGURE C-5: Transmission 2: HV_{OUT1} displayed instead of OE.




FIGURE C-6: Transmission 2: Zoom version, LE and HV_{OUT1} .

NOTES:



MICROCHIP

Worldwide Sales and Service

AMERICAS

Corporate Office

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
[http://www.microchip.com/
support](http://www.microchip.com/support)

Web Address:

www.microchip.com

Atlanta

Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX

Tel: 512-257-3370

Boston

Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago

Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Cleveland

Independence, OH
Tel: 216-447-0464
Fax: 216-447-0643

Dallas

Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Novi, MI
Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983

Indianapolis

Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453

Los Angeles

Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

New York, NY

Tel: 631-435-6000

San Jose, CA

Tel: 408-735-9110

Canada - Toronto

Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office

Suites 3707-14, 37th Floor
Tower 6, The Gateway
Harbour City, Kowloon

Hong Kong

Tel: 852-2943-5100
Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000
Fax: 86-10-8528-2104

China - Chengdu

Tel: 86-28-8665-5511
Fax: 86-28-8665-7889

China - Chongqing

Tel: 86-23-8980-9588
Fax: 86-23-8980-9500

China - Dongguan

Tel: 86-769-8702-9880

China - Hangzhou

Tel: 86-571-8792-8115
Fax: 86-571-8792-8116

China - Hong Kong SAR

Tel: 852-2943-5100
Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460
Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8864-2200
Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252
Fax: 86-29-8833-7256

ASIA/PACIFIC

China - Xiamen

Tel: 86-592-2388138
Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040
Fax: 86-756-3210049

India - Bangalore

Tel: 91-80-3090-4444
Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631
Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-3019-1500

Japan - Osaka

Tel: 81-6-6152-7160
Fax: 81-6-6152-9310

Japan - Tokyo

Tel: 81-3-6880-3770
Fax: 81-3-6880-3771

Korea - Daegu

Tel: 82-53-744-4301
Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857
Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870
Fax: 60-4-227-4068

Philippines - Manila

Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366
Fax: 886-3-5770-955

Taiwan - Kaohsiung

Tel: 886-7-213-7828

Taiwan - Taipei

Tel: 886-2-2508-8600
Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels

Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Dusseldorf

Tel: 49-2129-3766400

Germany - Karlsruhe

Tel: 49-721-625370

Germany - Munich

Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611
Fax: 39-0331-466781

Italy - Venice

Tel: 39-049-7625286

Netherlands - Drunen

Tel: 31-416-690399
Fax: 31-416-690340

Poland - Warsaw

Tel: 48-22-3325737

Spain - Madrid

Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

Sweden - Stockholm

Tel: 46-8-5090-4654

UK - Wokingham

Tel: 44-118-921-5800
Fax: 44-118-921-5820

07/14/15