

Semiconductor Heaters (CS, CSK, CSF) Quick Start Guide

1. Introduction

Dear Customer! Thank you for your purchase in TME! To protect the environment we have prepared for you this quick start guide. Before operating the unit, please read it carefully. Please visit www.tme.eu Illustrations in this manual are only example images and may differ from the actual item. It does not change their main characteristics.

2. Application

The device is designed for use in control cabinets for heating elements of industrial automation.

3. Application

- Install the device according to the type of the housing.
- Connect according to the diagram supplied by the manufacturer.

4. Precautions

- You must observe the technical data on the nameplate.
- Caution: There is a hot surface in the upper part of the grille.
- Danger of burns after the device is turned on!
- Installation of the device may only be performed by qualified technicians observing the regulations of local energy companies.
- For safety reasons and to maintain sufficient air circulation keep a minimum distance of 20mm from adjacent components and 50mm above and below the device.
- Device must not be mounted on combustible materials (i.e. wood, plastic, etc.)
- The device must be operated vertically i.e. the terminal blocks downwards.
- The device must be connected to the mains through the all poles circuit breaker.
- The device cannot be covered.
- The device can not be self-repaired and self-modified.
- Never use the device in an aggressive atmosphere.
- Never use the device if it has been damaged or is not working properly.



Transfer Multisort Elektronik Sp. z o.o.

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071
tel. +48 42 645 54 44, fax +48 42 645 54 70, export@tme.eu, www.tme.eu

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN